

SMART SITECOAT

Bitumen Rubber Latex Waterproofing Coating

PRODUCT DESCRIPTION

An alkali resistant cold applied rubberised bitumen emulsion which has excellent adhesion to sound building materials including asphalt. It retains flexibility in low temperatures and is resistant to softening in warm conditions. Sitecoat can be used to provide a flexible waterproof membrane on most building surfaces and may be extended to produce a flexible crack filler.

USES

- Waterproof coating to bridge abutments.
- Repairs to cracks in black top surfacing and concrete.
- Waterproofing concrete roofs.
- Fixing woodblocks and panel parquetry.
- Waterproofing walls and use as a keying treatment.
- Sandwich damp proof membranes, under concrete and roof screeds.

APPLICATION

Sitecoat should always be applied to surfaces which are clean and free from dust, oil and other surface contaminants. It should not be applied in temperatures below 50 and the applied material should be protected from frost or rain until it has completely dried. Drying time is 3 to 6 hours but this may be extended in humid or poorly ventilated situations.

Priming:

On very porous surfaces a priming coat should be used by preparing a mixture of 1 part Sitecoat to 5 part clean cold water. This should be thoroughly mixed before brushing on to the surface. It should be allowed to dry before subsequent treatments.

Waterproof Coating to Bridge Abutments:

The surface should be brush dampened with clean water or a priming coat brushed well in as described under priming. When this has dried apply two coats of Sitecoat. The second applied at right angles to the first after the first has been allowed to thoroughly dry.

Repairs to Cracks in Black Top Surfacing and Concrete:

Fine cracks may be filled with neat Sitecoat. Larger cracks up to approximately 6 mm are filled with a mixture

of 2 volumes of Sitecoat to 1 volume of fine sand. Cracks in excess of 6 mm should be filled with a similar mixture plus the addition of approximately 10% of Portland cement.

Neat Sitecoat may be poured into the crack, whilst filled mixtures are best applied with a pallet knife or similar. Repairs should be blinded with sand if early traffickin is intended. Larger repairs may need topping up after 24 hours.

Waterproofing Concrete Roofs:

Surfaces to be waterproofed should be thoroughly cleaned before brush dampening the surface with water or the Sitecoat priming mixture. When dry a coat of Sitecoat should be carefully applied and fibreglass tissue tamped into the surface, taking care to exclude any air pockets, whilst the Sitecoat is still wet. When dry a second coat of Sitecoat should be applied.

A third coat should be brushed well in after the second has dried. This final coat should be blinded with sharp sand or chippings to prevent cracking or crazing in areas which will be exposed to direct sunlight. Limestone chippings should not be used. Where tiles are used as the finish to the roof they should be placed in position only when the third coat of Sitecoat has reached a tacky state.

Fixing Wood Blocks and Panel Parquetry:

Wood blocks should have a minimum nominal thickness of 12.5 mm and be dipped bottom face only into the Sitecoat and placed immediately into position. On porous surfaces the Sitecoat priming mixture should be employed and allowed to dry before application. Woodblocks are more easily coated by pouring a small quantity of Sitecoat into a shallow container, then carefully dipping the base only of the blocks.

When fixing panel parquetry, as an alternative to dipping, Sitecoat may be spread evenly over a small area of floor and panels placed carefully into position.

Fixing Wood Blocks and Panel Parquetry:

Internal walls, glazed tiles and bricks etc may be treated to provide a waterproof membrane and a key for subsequent plastering. Sitecoat should be brush applied onto the clean surface and allowed to dry.

A second coat is then applied at right angles to the first and blinded with clean sharp sand whilst still wet. The final coat should be allowed to dry for at least 24 hours before plastering.

SMART SITECOAT

Bitumen Rubber Latex Waterproofing Coating

Sandwich Damp Proof Membranes, Under Concrete and Roof Screeds:

The slab to be treated should be thoroughly clean. If the slab is porous a priming mixture of Sitecoat should be applied and allowed to dry. Sitecoat should then be brushed evenly over the slab and the membrane applied so as to link up with any existing damp proof courses.

As soon as the first coat is dry apply a second at right angles and blind with clean coarse dry sand which will act as a key for the subsequent screed and protect the membrane during placing. A reinforcing membrane may be required at the junction between sub-floor and walls in common with good building practice.

CLEANING

Tools should be cleaned immediately after use with clean water. Where Sitecoat has hardened Sitewash should be used to soften the material.

TECHNICAL DATA

Coverage	1.1 to 1.7m ² per litre per coat of undiluted materials.
Packaging	205 litre drum, 25 litre bucket.
Storage	The material should be stored in a closed container and protected from the frost.
Shelf Life	1 year in sealed container when stored as recommended.

IMPORTANT NOTE

Whilst all reasonable care is taken in compiling technical data on the Company's products, all recommendations or suggestions regarding the use of such products are made without guarantee, since the conditions of use are beyond the control of the Company.

It is the responsibility of the customer to satisfy himself that each product is fit for the purpose for which he intends to use it, that the actual conditions of use are suitable, and that in the light of our continual research and development programme the information relating to each product has not been superseded.